



Mammoth X8 E-Scooter - Black

How to unlock your Mammoth X8 E-Scooter to 32km/h:

Step 1:

Press the "Function" & "Power" buttons at the same time until the screen displays "P0"



Step 2:

Press the "Function" button 4 times until the screen displays "P4"



Step 3:

Press the "Power" button which will then enter into the "P4" settings menu



Step 4:

Press the "Function" button to set the status so it displays as "FF"



(FF displayed means the scooter is unlocked to a max speed 32km/h)

Step 5:

Press the "Power" button to confirm the "FF" Status and exit the "P" settings



Step 6:

Press the "Function" & "Power" buttons at the same time to exit the menu setup

